

SECTION 10 – ELECTRICAL LOCK-OUT POLICY AND PROCEDURES

The Contractors/Constructors must follow George Brown College Lockout and Tagout Policy and Procedures or a procedure approved by George Brown College Coordinator which provides an equivalent level of safety. Contractors/Constructors must use their own locks and tags.